

**CHIC 130 ERRE SASH**
**Functions**

CHIC Sash is a mechanism used for manufacturing a modern and minimalist interior side-hung casement thanks to the possibility of combining CHIC hinges with 180° opening with the innovative SUPRA 7 window handle without rosette.

**Technical Features**

CHIC 130 ERRE Sash hardware is offered with concealed hinges used to make sashes up to a minimum width of 200 mm:

- 0° mechanism - closed sash
- 90° mechanism - open sash



Making a CHIC 130 ERRE Sash requires:

- CHIC 130 ERRE sash hinges
- SUPRA 7 or Cremone window handles and Giesse window handles
- Fastening mechanisms (terminals and strikers)

Sash minimum and maximum dimensions:

Width: 200 – 1500 mm

Height: 600 – 2500 mm.


**CONFIGURATION EXAMPLES**

**Single CHIC 130 ERRE Sash configuration (two-way)**

Article	Qty	Item code
<b>Supra 7 window handle</b>	1 pc.	04153 - 04154 - 04155 - 04156
<b>Two-way movement</b>	1 pc.	0102001
<b>Adapter kit</b>	1 pc.	01190
<b>Giap/Adjustable terminal</b>	2 pcs.	02141K - 02085
<b>Single striker</b>	2 pcs.	01317K
<b>Raising component</b>	1 pc.	02366
<b>CHIC - Sash hinge set</b>	1 pc.	052831 - 052832

**Double CHIC 130 ERRE Sash configuration (two-way)**

Article	Qty	Item code
<b>Supra 7 window handle</b>	1 pc.	04153 - 04154 - 04155 - 04156
<b>Two-way movement</b>	1 pc.	0102001
<b>Adapter kit</b>	1 pc.	01190
<b>Giap/Adjustable terminal</b>	2 pcs.	02141K - 02085
<b>Giap/Adjustable Bolt</b>	2 pcs.	02131K - 04347
<b>Double striker</b>	2 pcs.	01215
<b>Raising component</b>	2 pcs.	02366
<b>CHIC - Right-hand sash hinge kit</b>	1 pc.	052831
<b>CHIC - Left-hand sash hinge kit</b>	1 pc.	052832